



RP2040 GPIO HEADERS

J10 Conn_02x18_Odd_Even			J11 Conn_02x18_Odd_Even			
GPIO29	1	2	GND	1	2	GPIO0
GPIO28	3	4	GND	3	4	GPIO1
GPIO27	5	6	GND	5	6	GPIO2
GPIO26	7	8	GND	7	8	GPIO3
GPIO25	9	10	GND	9	10	GPIO4
GPIO24	11	12	GND	11	12	GPIO5
GPIO23	13	14	GND	13	14	GPIO6
GPIO22	15	16	GND	15	16	GPIO7
GPIO21	17	18	GND	17	18	GPIO8
GPIO20	19	20	GND	19	20	GPIO9
GPIO19	21	22	GND	21	22	GPIO10
GPIO18	23	24	GND	23	24	GPIO11
SWDIO	25	26	GND	25	26	GPIO12
SWCLK	27	28	GND	27	28	GPIO13
DVDD	29	30	GND	29	30	GPIO14
USB_BOOT	31	32	GND	31	32	GPIO15
DVDD	33	34	GND	33	34	GPIO16
RUN	35	36	GND	35	36	GPIO17

